

XV. PARTS

Item	Description	Size No.	QTY.
1	Upper Frame Arm		1
2	Lock Handle		1
3	Switch Plate		1
4	Guide Post		1
5	Support Bracket For Upper Guide		1
6	Screw		4
7	Guide Block		2
8	Square Guide Block		4
9	Cross Screw		8
10	Flat Washer		20
11	Knob Screw		4
12	Guard Plate		1
13	Sleeve		2
14	Ball Bearing	6200ZZ	2
15	C-Clip		2
16	Blade Adjust Screw		1
17	Upper Wheel Sliding Brkt.		1
18	Spring		1
19	Square Bolt		1
20	Knob Screw		1
21	Nut		1
22	Pan Screw		1
23	Upper Wheel Shaft Hinge		1
24	Pin		2
25	Spring Pin		1
26	Upper Wheel Shaft		1
27	Ball Bearing	6202ZZ	4
28	Upper Wheel		1
29	Wheel Protector		2
30	Upper Wheel Guard (Inner)		1
31	Stud		4
32	Upper Wheel Guard (Outer)		1
33	Screw		4
34	Flat Washer		8
35	Nut		6
36	C-Ring		4
37	Flat Washer		6
38	Pin		2
39	Screw		1
40	Flat Washer		2
41	Base		1
42	Nut		1
43	Saw Blade		1
44	Table Insert		1
45	Spring Pin		1
46	Pin		1
47	Working Table		1
48	Stud		2
49	Trunnion Clamp Shoe		2
50	Trunnion		2

Item	Description	Size No.	QTY.
51	Trunnion Support Bracket		1
52	Star Knob		6
53	Indicator		1
54	Gauge		1
55	Screw		2
56	Hexagon Stud		1
57	Hexagon Nut		4
58	Flat Washer		4
59	Hexagon Screw		2
60	Flat Washer		2
61	Support Bracket For Lower Guide		1
62	Nut		1
63	Lower Wheel		1
64	BLADE COVER		1
65	Key		1
66	Ball Bearing		2
67	C-Clip		2
68	Lower Wheel Shaft		1
69	Nut		1
70	Motor Pulley (Large)		1
71	Screw		1
72	Belt		1
73	Plate		1
74	Cross Screw		10
75	Switch		1
76	Motor		1
77	Motor Pulley (Small)		1
78	Key		1
79	Screw		1
80	Pulley Guard		1
81	Screw		4
82	Stand Foot		4
83	Screw		24
84	Adjusting Plate (L)		2
85	Adjusting Plate (S)		2
86	Stand		1
87	Washer		28
88	Nut		28
89	Motor Base		1
90	Screw		2
91	Shaft		1
92	Holder Base		1
93	Screw		1
94	Screw		1
95	Pulley		1
96	Nut		4
97	Motor Pulley Guard		1
98	Belt		1
99	Washer		2
100	Nut		1

A. PARTS BREAKDOWN

